


FIG. 2



3 / 10

FIG. 3




FIG. 4




FIG. 5





FIG. 6




7 / 10


FIG. 7A

DVD SETUP	
Picture Search	ON
SEARCH PLAYBACK TIME INTERVAL	30 SECONDS
AUDIO-DATA DESIGNATION OF CONTINUOUS PLAYBACK OF MUSIC PIECES	TRACK 2
...	..

FIG. 7B



**FIG. 8**





[illegible]

FIG. 10

